



# FILTERING FACEPIECE APPROVAL LABEL

Home Depot  
1 Concord Gate # 400  
North York, ON.  
M3C 4H9  
416-412-6767



THIS RESPIRATOR IS APPROVED ONLY IN THE FOLLOWING CONFIGURATION:

TC-	Protection <sup>1</sup>	Respirator	Cautions and Limitations <sup>2</sup>
		<b>SRS1010VHDXQ</b>	
84A-3889	N95	X	ABCJMNOPS

## 1. Protection

**N95-Particulate Filter (95% filter efficiency level) effective against particulate aerosols free of oil; time use restrictions may apply.**

## 2. CAUTIONS AND LIMITATIONS

- A- Not for use in atmospheres containing less than 19.5% oxygen.
- B- Not for use in atmospheres immediately dangerous to life or health.
- C- Do not exceed maximum use concentrations established by regulatory standards.
- J- Failure to properly use and maintain this product could result in injury or death.
- M- All approved respirators shall be selected, fitted, used, and maintained in accordance with MSHA, OSHA and other applicable regulations.
- N- Never substitute, modify add, or omit parts. Use only exact replacements parts in the configuration as specified by the manufacturer.
- O- Refer to User Instructions, and/or maintenance manuals for information on use and maintenance of these respirators.
- P- NIOSH does not evaluate respirators for use as surgical masks.
- S- **Special or critical User Instructions and/or specific use limitations apply. Refer to User Instructions before donning.**



### FITTING INSTRUCTIONS :

The respirator user must be fit tested according to OSHA regulation 29 CFR 1910.134.

1. Hold the respirator in one hand with the nosepiece at your fingertips, allowing the headbands to hang below your hand.
2. Press the respirator against your face with the nosepiece on the bridge of your nose.
3. Place the top band high on the back of your head. Move the bottom band over your head and position it below your ears.
4. Using both hands, mold the nosepiece to the shape of your nose.
5. Test the fit. Cup both hands over the respirator and inhale vigorously. If no negative pressure is felt inside the respirator, adjust the nosepiece. If any leakage is detected, readjust the position of the respirator according to steps #2 to #5 until you get a better fit.

### IMPORTANT LIMITATIONS:

1. All instructions and warnings have to be followed. Failure to do so will reduce the efficiency of the respirator and cause sickness or death.
2. Training on the proper use of the respirator must be provided by the employer in accordance with the safety and health standard.
3. Do not alter or modify the respirator.
4. Not suitable for persons with beard or other facial hair which may reduce the efficiency of the respirator.
5. The use and reuse of this respirator is subject to consideration of hygiene damage and increased breathing resistance. Service time should not be extended beyond 8 total hours of use.
6. Store the respirator in a cool place. Avoid direct exposure of sunlight during storage as the filter media in this respirator can be degraded by extended exposure to direct sunlight.
7. Before occupational use of this respirator, a written respiratory protection program must be implemented meeting all the local government requirements in the United States, employers must comply with OSHA 29 CFR 1910.134 which includes medical evaluation, training and fit testing.

### S- Special or critical User Instructions:

The model SRS1010VHDXQ filtering facepiece respirator has been manufactured by Jinfuyu Industrial Co., Ltd. for Home Depot under TC-84A-3889.