

User Instructions

LiveFree Personal Protection LLP
3411 Hawthorne Road, Pocatello, ID 83201
1-888-215-2880

USER'S INSTRUCTIONS *IMPORTANT: Before use, the wearer must read and understand these instructions.*

USE FOR: Solids such as those from processing minerals, coal, iron ore, flour, and certain other substances; liquid or non-oil-based particles from sprays that do not also emit oil aerosols or vapors.

DO NOT USE FOR: Paint spray, oil aerosols, gases, vapors, asbestos, or sandblasting. This respirator does not supply oxygen.

USE INSTRUCTIONS: [1] Failure to follow all of the instructions and limitations on the use of this respirator and/or failure to wear this respirator properly during all times of exposure can reduce respirator effectiveness and may result in sickness or death. [2] Before occupational use of this respirator, a written respiratory protection program must be implemented meeting the requirements of OSHA 29 CFR 1910.134, such as training, fit testing, and applicable OSHA substance specific standards. [3] The particles which can be dangerous to your health include those so small you cannot see them. [4] Leave the contaminated area immediately and contact your supervisor if dizziness, irritation, or other distress occurs. [5] Store the respirator away from contaminated areas when not in use. [6] Dispose of use product in accordance with applicable regulations.

USE LIMITATIONS: [1] This respirator does not supply oxygen. Do not use in atmospheres containing less than 19.5% oxygen. [2] Do not use where the concentration of contaminants is immediately dangerous to life and health or is unknown. In addition, do not use when the concentration exceeds ten (10) times the Permissible Exposure Level (PEL), the specific applicable OSHA standard, or other

applicable government regulations, whichever concentration level is lowest. [3] Do not alter, abuse, or misuse this respirator. [4] Do not use with beards or other facial hair or any other conditions that prevent a good seal.

TIME USE LIMITATIONS: If the respirator becomes damaged, soiled, or breathing becomes difficult, leave the contaminated area and replace the respirator.

LIMITED WARRANTY: This limited warranty is made in lieu of the warranties of merchantability, fitness for particular purpose, and all other warranties, express or implied. There are no other warranties which extend beyond this limited warranty as set forth herein. The manufacturer warrants this product against manufacturing defects. The exclusive remedy for breach of this warranty is the replacement of the product proved to have been defectively manufactured, and damages are expressly limited replacement of the defective merchandise. Except as provided above, LiveFree shall not be liable for

any loss, damage, or liability, direct, indirect, incidental, special, punitive, exemplary, or consequential, arising out of the sale, use, misuse, or inability to use the products by any user.

Donning Instructions

HOW TO WEAR THE N95 RESPIRATOR MASK

1  WASH YOUR HANDS AND OPEN MASK WITH DRY HANDS. STRETCH THE TOP AND BOTTOM STRAPS BEFORE PUTTING ON THE RESPIRATOR.

2  PLACE THE TOP STRAP HIGH ON THE BACK OF YOUR HEAD. PLACE THE BOTTOM STRAP AROUND THE NECK BELOW THE EARS.

3  CAREFULLY POSITION THE RESPIRATOR ON YOUR FACE SO THAT IS UNDER YOUR CHIN WITH THE METAL STRIP COVERING YOUR NOSE.

4  USING BOTH HANDS, GENTLY BEND THE NOSE PIECE TO FIT THE CONTOURS OF YOUR FACE FOR A SNUG FIT BETWEEN THE MASK AND YOUR NOSE.

5  CHECK THE RESPIRATOR FIT BY PLACING BOTH HANDS OVER THE RESPIRATOR AND EXHALING.

6  DO NOT USE WITHOUT A PROPER FIT.

IF AIR LEAKS AROUND THE NOSE, ADJUST THE NOSEPIECE. IF AIR LEAKS AROUND ANY OTHER PORTION OF THE FACE, ADJUST THE STRAPS. IF YOU CANNOT ACHIEVE A PROPER FIT, CONTACT A SUPERVISOR OR GET ANOTHER PERSON TO HELP YOU MAKE ANY NEEDED ADJUSTMENTS.