

S- SPECIAL OR CRITICAL USER'S INSTRUCTIONS:

The model number RA3836V filtering facepiece respirator has been manufactured by FIDO Masks Co., Ltd. for Kimberly-Clark under TC-84A-9658.

- This respirator offers nuisance level relief from organic vapors that are below the permissible exposure limit (PEL). Nuisance level refers to concentrations not exceeding the OSHA PEL or other government occupational exposure limits, whichever is lower.

FITTING INSTRUCTIONS:

1. Place the respirator over your nose and mouth. Be sure the nose shape position in on top.
2. Pull the bottom strap over your head until it rests below the ears at the back of your neck. Untwist the strap.
3. Pull the top strap over your head until it rests on the crown of your head above your ears. Untwist the strap.
4. Without removing the respirator, adjust the straps until the respirator is secure. To tighten the respirator, gently pull the ends of both straps. To loosen the respirator, press back side of the buckle.
5. To check the correct fit, cup the respirator with both hands and inhale sharply. If any air flow indicates leakage around the edges of the respirator stretch the headbands again by pulling them backwards. Then correct the position of the respirator (see picture) and check again.

Note: Pinching the nosepiece using one hand may result in improper fit and less effective respirator performance. Use two hands.

DO NOT enter a contaminated area if a proper fit cannot be obtained. See your supervisor for proper fitting respiratory protection.

