

User's Instructions for Kimberly-Clark Model No. 47424



For Professional & Frequent Do-it-yourselfers:

Effective against oil-based and non oil-based particulate aerosols and dust that do not emit harmful vapors during home improvement tasks.

R95 Particulate Mask R95 Particulate

IMPORTANT: Follow all instructions and warnings on the use of this mask ("respirator"). Wear during all times of exposure. Failure to do so will reduce mask effectiveness and user protection, and may result in sickness or death.

Use for:

- Oil-based Particulates • Automotive Repair • Woodworking
- Drywall • Sanding • Fiberglass

Time use limitations: If mask becomes damaged, soiled, or breathing becomes difficult, leave the contaminated area and properly dispose of the mask. If oil is present, it is recommended that the mask be used only for one shift (or for 8 hours of continuous or intermittent use).

Effective against oil-based and non-oil based particulate aerosols and dust that do not emit harmful vapors. Before occupational use, OSHA requires the user be fit tested with this model of respirator per regulation 29 CFR 1910.134.

Fitting Instructions: Follow these instructions each time mask is worn.



1. Open mask to expose and separate headbands. Make sure nosepiece is on top of the mask.
2. While holding headbands with your index finger and thumbs, cup the mask under your chin.
3. Pull straps over your head and place the lower strap at the base of your neck and the upper strap on the crown of your head.
4. Conform the nosepiece across the bridge of your nose by firmly pressing down with your fingers. Check to ensure no air leaks around the edge of the mask.
5. Continue to adjust until you have achieved a good facial fit.



Kimberly-Clark
P.O. Box 2020
Neenah, WI 54957-2020
1-800-558-8810



This respirator is approved only in the following configuration:

| TC- | Protection ¹ | Respirator | Cautions and Limitations ² |
|----------|-------------------------|------------|---------------------------------------|
| 84A-4111 | R95 | 47424 X | ABCJMNO PS |

1. PROTECTION:

R95-Particulate Filter (95% filter efficiency level) effective against all particulate aerosols; time use restrictions may apply.

2. CAUTIONS AND LIMITATIONS:

- A. Not for use in atmospheres containing less than 19.5 percent oxygen.
- B. Not for use in atmospheres immediately dangerous to life or health.
- C. Do not exceed maximum use concentrations established by regulatory standards.
- J. Failure to properly use and maintain this product could result in injury or death.
- M. All approved respirators shall be selected, fitted, used, and maintained in accordance with MSHA, OSHA, and other applicable regulations.
- N. Never substitute, modify, add, or omit parts. Use only exact replacement parts in the configuration as specified by the manufacturer.
- O. Refer to users instructions, and/or maintenance of these respirators.
- P. NIOSH does not evaluate respirators for use as surgical masks.
- S. Special or critical User's Instructions and/or specific use limitations apply. Refer to User's Instructions before donning.

WARNING!

1. Do not use for sandblasting or to protect against asbestos, lead-based paint, pesticides, vapors or gases.
2. Do not wear this mask when conditions prevent a good facial seal. It is important to fit check the mask each time it is worn.
3. This mask is not for medical use.
4. Never alter or modify this product.
5. Special Instructions: The model 47424 filtering facepiece respirator has been manufactured by San Huei United Co., Ltd. for Kimberly-Clark under NIOSH TC-84A-4111.

® / * Trademarks of Kimberly-Clark Worldwide, Inc.
Marques déposées de Kimberly-Clark Worldwide, Inc.
© 2007 KCWW.

Made in China / Fabriqué en Chine / Fabricado en China
Distributed in the U.S. by Kimberly-Clark Global Sales, LLC, Roswell, GA 30076-2199
Distributed in Canada by Kimberly-Clark Inc., Mississauga, Ontario L5B 3Y5
www.kcdiy.com 20-29-069-0-04