


-----W: 150mm-----



SM or ML

N95
NIOSH
APPROVED

321 HORIZONTAL FOLD FLAT DISPOSABLE DUST MASK



PACK OF
10

135mm-----

-----W: 135mm-----



N95
NIOSH
APPROVED

FITTING INSTRUCTIONS

THE RESPIRATOR USER MUST BE FIT TESTED ACCORDING TO OSHA REGULATION 29 CFR 1910.134.



1. Bend the nosepiece to open the respirator and create a cup shape suitable for fitting onto your face.



2. Hold the respirator in one hand with nose piece at your fingertips, allowing the headbands to hang below your hand.



3. Press the respirator against your face with the nose piece on the bridge of your nose, pulling the straps over your head. Move the bottom strap over your head and position it below your ears. Place the top strap high on the back of your head.



4. Adjust the strap tension by pulling the ring adjuster until a comfortable fit is achieved.



5. Using both hands, mould the nose piece to the shape of your nose.



6. Test the fit. Cup both hands over the respirator and exhale vigorously. If air flows around your nose, tighten the nose piece. If air leaks around the edge, reposition the straps for better fit.

IF YOU CANNOT ACHIEVE A PROPER FIT, DO NOT ENTER THE CONTAMINATED AREA. SEE YOUR SUPERVISOR FOR PROPER FITTING RESPIRATORY PROTECTION.



SM or ML

N95
NIOSH
APPROVED

321 HORIZONTAL FOLD FLAT PARTICULATE RESPIRATOR



PACK OF
10



N95
NIOSH
APPROVED

APPLICATIONS

Before use, wearer must read and understand these instructions. Keep user instructions for reference.

USE AGAINST:

NIOSH approved for protection against particulate aerosols free of oils. JSP recommends this respirator for use against particulate such as flour, iron, coal and minerals.

DO NOT USE AGAINST:

1. Vapours, paint spray, oil-based aerosols, asbestos and sand blasting.
2. Any contaminant whose concentration is unknown, or immediately dangerous to life or health.
3. Concentrations of Dust Mists which exceed the maximum use concentration or 10 times contaminant's permissible exposure limit established by OSHA or applicable government occupational exposure limits, whichever is lower.

WARNING:

1. These respirators do not supply Oxygen. Do not use in atmospheres containing less than 19.5% Oxygen.
2. Leave contaminated area immediately if the respirator becomes damaged, proper fit cannot be obtained or breathing becomes difficult. Dispose and change the respirator.
3. The respirator has been tested. Small punctures around the staples are normal and do not interfere with the respirator compliance with 42CFR Part 84 approval requirements. However, it is subject to inspection prior to each use to assure there are no holes in the breathing zone other than the punctures around the staples and no damage has occurred.
4. Before occupational use of this respirator, a written respiratory protection program must be implemented meeting all requirements of OSHA 29CFR 1910.134 such as training, fit testing, medical evaluation and applicable OSHA substance specific standards.

IMPORTANT LIMITATIONS:

1. All instructions and warnings have to be followed. Failure to do so may reduce the efficiency of the respirator and may cause sickness or death.
2. Training on the proper use of respirator must be provided by the employer in accordance with safety and health standards.
3. Do not alter, misuse or modify the respirator.
4. Not suitable for persons with beards or other facial hair which may reduce the efficiency of respirator.
5. The use and reuse of this respirator is subject to consideration of hygiene, soiling, damage and increased breathing resistance. Service time should not be extended beyond 8 total hours of use.
6. Store in a cool dry place. Avoid direct exposure to sunlight during storage as the filter media in this respirator can be degraded by extended exposure to direct sunlight.
7. This respirator is designed for occupational/professional use by adults who are properly trained in their use and limitations. This respirator is not designed to be used by children.



N95
NIOSH
APPROVED

FILTERING FACE PIECE APPROVAL LABEL



JSP LTD Worsham Mill,
Minster Lovell, Oxford, OX29 0TA, England
+44 1993 824000



321 N95 Horizontal fold flat particulate respirator

THIS RESPIRATOR IS APPROVED ONLY IN THE FOLLOWING CONFIGURATIONS:

TC	Protection ¹	Respirator		Caution and Limitations ²
		321SM	321ML	
84A-6268	N95	X	X	ABC,IM,NOP

1. Protection

N95 - Particulate Filter (95% filter efficiency level) effective against particulate aerosols free of oil; time use restrictions may apply

2. Caution and Limitations

- A - Not for use in atmospheres containing less than 19.5% Oxygen.
B - Not for use in atmospheres immediately dangerous to life or health.
C - Do not exceed maximum use concentrations established by regulatory standards.
J - Failure to properly use and maintain this product could result in injury or death.
M - All approved respirators shall be selected, fitted, used, and maintained in accordance with MSHA, OSHA and other applicable regulations.
N - Never substitute, modify, add, or omit parts. Use only exact replacement parts in the configuration as specific by manufacturer.
O - Refer to user's instructions, and/or maintenance manuals for information on use and maintenance of these respirators.
P - NIOSH does not evaluate respirators for use as surgical masks.



WARNING

NIOSH APPROVED: N95 95% filtration efficiency against solid and liquid aerosols that do not contain oil. This respirator helps protect against certain particulate contaminants but does not eliminate exposure to or the risk of contacting disease or infection. MISUSE MAY RESULT IN SICKNESS OR DEATH.

IMPORTANT NOTICE TO PURCHASER:

The following warranty is made in lieu of all other warranties expressed or implied, including but not limited to, the implied warranties of merchantability and fitness for purpose. Manufacturer warrants this product to be free from defect. Manufacturer's only obligation shall be, at our option, to replace any portion providing defective or to refund the purchase price thereof. User shall determine the suitability of the product for his intended use, and assume all risks and liability in connection therewith.



Manufacture Date:

Expiry Date:

Lot No.:

Technical Helpline Tel: +44 1993 826051
E-Mail: technical.service@jsp.co.uk

* JSP Ltd 2012, issued 05/12. All Rights Reserved. JSP LTD Worsham Mill, Minster Lovell, Oxford, OX29 0TA, England
Tel: +44 1993 826050 Fax: +44 1993 824411 technical@jsp.co.uk export@jsp.co.uk www.jsp.co.uk
Made in China

-----H: 135mm-----

-----H: 230mm-----

-----H: 230mm-----